

Dear Parent,

At LeapFrog, we are constantly developing new ideas designed to build a child's confidence and inspire a love of learning.

This year we've introduced our groundbreaking LeapZone™ line of fun, interactive, personal, portable tutors. We know that all children learn best at their own pace. Therefore, all LeapZone products include MindLink™, a groundbreaking educational technology that enables each product to adapt to each child at exactly the appropriate pace and learning level. In addition, by connecting to LeapFrog's Web site, you can download new lessons, refueling your product with personalized content designed to help your child achieve the next level of learning. You can even use the online assessment feature to track your child's progress and stay involved in the learning process.

LeapZone learning tools come to life, offering just the right degree of fun and challenge to keep your child captivated. We hope these new products will help you create an engaging environment for your child—one that encourages discovery and fosters learning success.

Sincerely,
Michael C. Wood

Mike Wood

Founder and President

Look for More Fun Learning Toys from LeapFrog®!



Count & Sing Express™

Lovable Lily™

Flying Friends™



LeapZone
leapfrog.com
Internet
Compatible

Leap's Learning Band™

Fun & Learn Phonics Bus™



#1 Learning toy in the USA!

LeapPad™/LeapPad Pro™

LeapPad™ Library of Books

A large LeapFrog toy, the School Time LeapTop™, is shown on a yellow background. It is a blue and white toy with a screen, a keyboard, and a clock. A small green frog character is visible on the screen. The text "School Time LeapTop™" is written in the top right corner. The LeapZone logo is in the top left corner. A small inset photo shows a child using the toy. The text "Parent Guide and Instructions" is written in the bottom left corner, followed by "This guide contains important information. Please keep it for future reference." and "Internet Compatible". The website "Visit www.leapfrog.com for details." is written at the bottom.

Parent
Guide and
Instructions

This guide contains important information.
Please keep it for future reference.

Internet
Compatible

Visit www.leapfrog.com for details.

Thanks for purchasing the School-Time LeapTop™ from LeapFrog! You've just taken another step toward inspiring your child to develop a lifelong love of learning.

It's **easy to get started**. Just turn the LeapTop on and start having fun learning words and math!

Imagine...a toy that **modifies the degree of difficulty** automatically and keeps your child in the most effective learning zone as he or she plays! That's the power of the new technology inside the LeapTop.

And did you know the LeapTop **connects to the Internet**? You can expand its capabilities by subscribing to the LeapZone Advantage™ learning service to:

- **add many more words**
- **assess your child's progress**
- **download new learning games and more great content!**

LeapFrog® has partnered with leading experts in education, including Dr. Robert Calfee, Professor Emeritus, Stanford University Graduate School of Education, to assure that the proper levels of complexity and presentation are incorporated into each of its learning toys. Standards advocated by leading organizations such as the *National Council for Teachers of Mathematics*, *National Council for Teachers of English*, *Association for Supervision and Curriculum Development* and the *National Council for Social Studies* have been incorporated to ensure that our products help your child succeed in school.

Internet Compatible!

Expand your School-Time LeapTop with the LeapZone Advantage learning service.

What is it?

- An internet-based learning service that turns your School-Time LeapTop into a Personal Brain Trainer™.

What are the benefits?

- Access to new themes and words make learning fun!
- New games and activities downloaded to your School-Time LeapTop keep the learning experience fresh and exciting.



- Detailed assessments of your child's progress.
 - Content tailors each game to your child's interests. Your child will even be called by name!
- How can I subscribe?**
- Get a LeapLink™ at your favorite retail store or online retailer and we will give you a **FREE** trial Silver Membership to the LeapZone Advantage learning service (membership service required).
 - One LeapLink works with **ALL** LeapZone products.
 - Please visit our Web site at www.leapfrog.com for a demonstration.

SAMPLE ASSESSMENT REPORT

School-Time LeapTop™

PRESS LEAP OR LILY FOR HELPFUL HINTS AS YOU LEARN AND PLAY!

SLIDE THE GAME MODE SELECTOR TO PICK ONE OF SEVEN GAME MODES

PRESS THE NUMBERED APPLE KEYS TO INPUT YOUR ANSWERS

ADJUST THE VOLUME HIGH OR LOW

PRESS THE LETTER KEYS FOR VOWELS AND CONSONANTS IN THE SPELLING GAMES

INSERT LEAPLINK CARTRIDGE TO UPDATE CONTENT (sold separately)



HOW TO PLAY

BEFORE YOU START! – To ensure proper function and initial challenge level for your child, the unit will need to be reset. Hold down the character “Leap” (on the right side of the piano as you face the LeapTop™) and the letter “P” while sliding the “Pencil” to turn the unit on. A sound effect will let you know the unit is reset.

Multiple learning game modes make learning fun!

ABC 123 - Letter Names & Sounds

Learn letter names, sounds and numbers through rhymes.

1. Turn on the LeapTop by moving the game mode selector to the first position ABC123. LeapTop will ask your child to identify letter names and sounds by its corresponding letter.
2. Input the correct letter and LeapTop confirms the correct answer. If an incorrect answer is input, LeapTop will say the incorrect letter. If your child needs a hint, toggle the indicated character.

5-A-I - Learn the Words

Learn the first letter in 26 different words and identify numbers with number rhymes.

1. Move the game mode selector to the second position. LeapTop displays a word and asks your child to find the letter that corresponds to the first sound in the word.
2. Input the correct letter and LeapTop confirms the correct answer. If an incorrect answer is input, LeapTop will say the incorrect letter. If your child needs a hint, toggle the indicated character.

!-?-? - Mystery Letter

Identify the missing letter in a word.

1. Move the game selector to the third position. LeapTop will ask your child to identify the letter that corresponds to a particular letter name or sound in the word displayed on the screen.
2. Input the correct letter and LeapTop confirms the correct answer. If an incorrect answer is input, LeapTop will say the incorrect letter. If your child needs a hint, toggle the indicated character.

?-?-? - Create a Word

Create your own 3 letter words and fun sounds.

1. Move the game selector to the fourth position. LeapTop will ask your child to create a three letter word.
2. LeapTop repeats the word or sound your child has made.

123 - Counting

Find the numbers. Leap and Lily help you along.

1. Move the game selector to the fifth position. LeapTop asks your child to find on the keyboard the number it requests and displays it on the screen.
2. Input the correct number and LeapTop confirms your child's answer. If the incorrect number is input, LeapTop will say the wrong number and repeat the question. If your child needs a hint, toggle the indicated character.

+ - - Addition/Subtraction

Simple addition and subtraction problems.

1. Move the game selector to the sixth position. LeapTop will ask your child to solve a problem of addition or subtraction.
2. Input the correct number and LeapTop confirms the correct answer. If an incorrect answer is input, LeapTop will say the incorrect number. If your child needs a hint, toggle the indicated character.

🌐 - Internet

Play new games by downloading new scenarios on favorite topics. School-Time LeapTop feels like a new toy every time you download! Using your LeapLink™ and Internet data cartridge (sold separately), you can link your unit to the www.leapfrog.com Web site (membership service required).

Off

Turn the game selector to the off position. If the unit is not used for more than 60 seconds, the unit will automatically shut-off.

Customer Service Information:

IMPORTANT: Please notify the LeapFrog® Customer Service department of any difficulties at (800) 701-LEAP (5327) before returning this product for any reason. Returns must have a Return Authorization number (RA#) in order to be processed. If the service representative is unable to solve the problem, you will be given instructions on how to replace the product.

Battery Information:

The School-Time LeapTop unit will notify you when the batteries are getting low.

To improve performance, replace low batteries with 4 new AA (LR6 in some countries) alkaline batteries.

Battery Safety:

- Batteries are small objects. Only adults may perform battery replacement.
- Follow the polarity (+/-) diagram in the battery compartment.

- DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard).
- DO NOT use rechargeable batteries.
- Dispose of used batteries properly. DO NOT incinerate used batteries.
- DO NOT recharge non-rechargeable batteries.
- Promptly remove dead batteries from the toy.

Battery Installation:

- School-Time LeapTop requires 4 AA (LR6 in some countries) alkaline batteries.
 - When the batteries run low on power, the toy's speech may become garbled or it may repeat itself. Replace the batteries at this time.
1. Open the battery door with a screwdriver. (The battery door is located on the bottom of the unit.)
 2. Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
 3. Replace battery door securely.

TROUBLE-SHOOTING

Symptom:	Try This:
Toy does not turn on or does not respond	<ol style="list-style-type: none"> 1. Remove batteries and put them back in. 2. Make sure battery cover is correctly secured. 3. Clean battery contacts with rubbing alcohol. 4. Install new AA alkaline batteries.
Toy makes strange sounds or behaves erratically	Install new AA alkaline batteries
Toy makes improper responses	Check batteries

This device complies with Part 15 of the FCC rules.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This toy generates, uses, and can radiate radio frequency energy. However, there can be no guarantee that interference will not occur. If this toy does cause interference to radio or television reception (you can check this by turning the toy off and on while listening for the interference), one or more of the following measures may be useful:

- Reorient or relocate the receiving antenna
- Increase the separation between the toy and the radio or the TV
- Consult the dealer or an experienced TV-radio technician for help

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

LeapFrog Warranty

This LeapFrog product warranty applies only to the original purchaser for a period of three months from the original purchase date, under normal use and service, against defective workmanship and material. This warranty is void if the product has been damaged by accident or unreasonable use, immersion in water, neglect, abuse, battery leakage or improper installation, improper service, or other causes not arising out of defects in workmanship or materials. Repair or replacement as provided under this warranty is the exclusive remedy of the purchaser. LeapFrog shall not be liable for any incidental or consequential damages for breach of any express warranty on this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the duration of this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

During the warranty period, your product will either be repaired or replaced at LeapFrog's option, when returned, shipping prepaid and with proof of purchase date as instructed by a LeapFrog service representative. In the event that your product is replaced, the replacement will be covered under the original warranty or for 30 days, whichever is longer.

Patents pending. LEAPFROG is a registered trademark of Knowledge Kids Enterprises, Inc. LEAPZONE, LEAPLINK, and SCHOOL-TIME LEAPTOP are trademarks of Knowledge Kids Enterprises, Inc. © 2000 Knowledge Kids Enterprises, Inc. All rights reserved.

Made in China

Visit our fun-filled Web site at:
www.leapfrog.com

For more information about LeapFrog products, call (800) 701-LEAP (5327).
1400 65th Street, Suite 200
Emeryville, CA 94608-1071

Requires 4 AA/ LR6 alkaline batteries.

For ages 3 and up.